




2 sec.



min




2 sec.



1x



Area




Transfer value from main line by pressing



2x



Volume



Transfer value from main line by pressing



2 sec.



Quick Start

Leica DISTO™ X1



- 1 Display
- 2 ON/Measure
- 3 Add
- 4 Clear/OFF
- 5 Measuring Reference
- 6 Functions/Settings
- 7 Subtract

- when it has to be **right**



FUNC

2 sec.

Settings

FUNC	2 sec.	1.1		0.000 m 0.0000 m 0.000 in	0.00 ft 0'00" 1/32 0 in 1/32
FUNC /		2.1			
FUNC /		3.1			
FUNC /		4.1			

Change settings in submenu / turn function ON/OFF

FUNC 2 sec.

www.disto.com

User Manual:



ON



OFF

2 sec.

