How to activate your Authentication Code

1. Introduction

In this guide, the activation of an authentication code and therefore the upgrade of GNSS options for all Leica Zeno hardware is documented, with the use of different Leica Zeno software available.
Upgradable devices are:

- GG03/GG04/GG04 plus
- Zeno 20 Windows
- Zeno 20 Android
- CS25 GNSS

The upgrade of the aforementioned devices can be implemented with the help of different software.

Upgradable device	Software to be used for the activation (click on the hyperlink)
GG03/GG04/GG04 plus	Zeno Mobile/Connect
Zeno 20 Windows	Zeno Tools
Zeno 20 Android	Zeno20 Mobile/Connect
CS25 GNSS	Leica Zeno GNSS Upgrade Key

- when it has to be right

2. Zeno20: Zeno Mobile /Connect

1. Connect to your antenna via Zeno Mobile
2. Press the 3 dots next to Zeno 20
3. Open the "Upgrade Antenna" option provided in the Antenna Settings

4. Select the preferred method to get your Auth-Code

Upgrade Antenna

Get Auth-Code Online
Get Auth-Code from your myWorld-Account.

Set new authentification code
Enter Auth-Code

Browse Auth-Code File
Browse for a license key

- *Get Auth-Code online*: To be able to use this function, you should activate your product in MyWorld
- *Set new authentification code*: Type the code showed in MyWorld webpage[1]
- *Browse Auth-Code File*:
  1. Tap on "Download Keys" in MyWorld webpage to download the key[2]
  2. Browse the file

my Tools ▸ myWorld ▸ myProducts   ✉ Send to   🖨 Print page

Overview   Manuals

Back   2   Download Keys   Calibration Certific   Help

General

Product:	GG04 plus Professional	Article No.:	867128
My Reference:	[Save]	Delivery Date:	
Serial No.:	207653	Equipment No.:	7645299
Warranty Start:	06.07.2017	Warranty End:	05.07.2018

Hardware

Measurement Engine HW Version:	1.02	ME Serial No.:	DMGW17070029C
Glonass:	Yes	Galileo:	No
BeiDou:	No	Multi Frequency:	Yes
RTK:	Yes		

Software

Measurement Engine SW Version:	7.03.00

Licensing

Authentication Code: Key: 1   9WF4B8,HPFBNT,PT2J9T,FFBXM3,N5C326,DFNRNNTVN

Customer Care Package

Customer Care Packages ensure to keep your product up-to-date and in top condition to ensure you are getting maximum benefit from the investment. Customer Care Packages are flexibly offered with contents such as Hardware Maintenance, Software Maintenance.

Please contact your local Leica Geosystems Sales Representative or Distributor for advice and purchasing information on Customer Care Packages.

Service History ›

Leica Geosystems

3. Zeno Tools

Before you activate your authentication code by using Zeno Tools, **the GPS must be switched on manually through the device settings.**

3.1. GPS activation

1. Open device Settings
2. Tap on "System"
3. Open GPS settings
4. Press the left arrow to access the "Power Manager"
5. In the "Power Manager" you can see the "GPS Power Control"
6. Switch on the GPS

- when it has to be **right**

Leica Geosystems

3.2. Authentication Code Activation
1. Open "Zeno Tools"
2. Tap on "GNSS Upgrade Key"
3. Check if the COM Port is the correct one
4. Click on Authorization Code field to type the Auth-Code
5. Press OK for the activation process to start

- when it has to be **right**

4. Zeno Mobile/Connect

1. Connect to your antenna via Zeno Mobile/Connect
2. Press the 3 dots next to your antenna
3. Open the "Upgrade Antenna" option provided in the Antenna Settings

4. Tap on "Set new authentification code" to enter your Auth-Code

4. Leica Zeno GNSS Upgrade Key

1. Open "Leica Geosystems" folder from your Desktop
2. Search for "GNSS Upgrade Key"

3. Open GNSS Upgrade Key

4. Click on the arrow on the right to see the available com ports (see Figure above)
5. Select the com port, through which your antenna is connected to your device
6. Type the Authorization code at the corresponded field
7. Press OK to start the process

- when it has to be **right**